

TELLER CASH TRAYS

PART #	TYPE	COMPARTMENTS
5000	Cash Tray Kit with 2 Coin Scoops	10
5000TP	Cash Tray Kit with 2 Coin Scoops	10
5000BP	Cash Tray Kit with 2 Coin Scoops	10
5600	Cash Tray Kit with Coin Rack	6
5600TP	Cash Tray Kit with Coin Rack	6
5600BP	Cash Tray Kit with Coin Rack	6
5001	Cash Tray	10
5001BP	Cash Tray	10
5601	Cash Tray	6
5601BP	Cash Tray	6
5501TP	Cash Tray	5
5553TP	Cash Tray Lid with lock	5
5002	Plastic Coin Scoop Insert	
5002BP	Plastic Coin Scoop Insert	
5003	Metal Cash Tray Lid with Lock	
5003TP	Plastic Cash Tray Lid with Lock	
5003BP	Plastic Cash Tray Lid with Lock	
5701	Teller Coin Tray	
5701B	Teller Coin Tray	
LOCK SET	CASH TRAY LOCK SET	2 KEYS

COLOR	LID TYPE
Tan	Metal
Tan	Plastic
Black	Plastic
Tan	Metal
Tan	Plastic
Black	Plastic
Tan	
Black	
Tan	
Black	
Tan	
Tan	Plastic
Tan	
Black	
Tan	
Tan	
Black	
Tan	
Black	